



# CRUISE CONTROL SYSTEM Parts Location




## 3VZ-E ENGINE



7.8 (80, 69 in.-lbf)

N·m (kgf·cm, ft·lbf) : Specified torque


**22R-E ENGINE**



BE3035


# Wiring Diagram

- \*1 RESUME/ACCEL Switch
- \*2 SET/COAST Switch
- \*3 CANCEL Switch



# Connector Diagrams

Cruise Control ECU



Main Relay




Main Switch




Cruise Control Switch




Slip Ring Speed  
(Control Switch Side)



(Wire Harness Side)




Actuator




Vacuum Pump




Vacuum Switch




Stop Light Switch




Data Link Connector 1




Parking Brake Switch



Clutch Switch



Park/Neutral Position Switch



# System Description

## Standby Operation

- When the ignition switch is turned ON (IG), current flows from the battery to terminal 6 of the Cruise Control ECU (hereafter called ECU).
- When the ignition switch is turned ON (IG), current flows from the battery to terminal 2 of the Main Relay.

## Operation

### 1. MAIN SWITCH OPERATION

When the main switch is pushed ON, current flows from terminal 2 of the main relay → terminal 4 → terminal 4/6 of the slip ring → terminal 3/5 → terminal 3/5 → of the cruise control switch (hereafter called SCS) → terminal 1/2 → terminal 1 of the main switch → terminal 2 → terminal 2/2 of the SCS → terminal 4/5 → terminal 4/5 of the slip ring → terminal 5/6 → ground.

As a result, the main relay turned ON → current flows to terminal 12 of ECU.

After that, current flows through the "CRUISE" indicator light to terminal 4 of the ECU.

Therefore, the main switch remains on and continues to supply current to terminal 12 of the ECU.

### 2. SPEED CONTROL SWITCH OPERATION

The cruise control switch controls the SET, COAST, RESUME, ACCEL and CANCEL functions.

When the each speed control switch is pushed ON, sends a signal (each voltage) from terminal 2/5 of the SCS → terminal 2/5 of the slip ring → terminal 6/6 → terminal 19 of the ECU.

Then, the vehicle speed at the moment the switch (SET position) is released is registered in memory.

### 3. SPEED CONTROL OPERATION

When the vehicle speed is set by the cruise control switch, the ECU send a signal from terminal 3 of the ECU → terminal 2 of the stop light switch → terminal 4 → terminal 1 of the actuator (release valve side).

At the same time, the ECU sends a signal from terminal 5 of the ECU → terminal 2 of the actuator (control valve side).

Then, the actuator increases or decreases the throttle valve opening angle in accordance with the signal from the ECU.

### 4. CANCEL OPERATION

The Cruise Control System is provided with several types of the cancel, such as the cruise control switch (CANCEL), the stop light switch, the parking brake switch and the park/neutral position switch (AM or clutch switch (M/T)).

#### (a) Cruise Control Switch (CANCEL)

When the cruise control switch (CANCEL) is pushed ON, sends a cancellation signal from terminal 2/5 of the SCS → terminal 2/5 of the slip ring → terminal 6/6 → terminal 9 of the ECU.

#### (b) Parking Brake Switch

When the parking brake lever is pulled, the parking brake switch turned ON → Sends a cancellation signal (ground voltage) to terminal 14 of the ECU.

#### (c) Park/Neutral Position Switch (A/T)

When the shift lever is set to the "N" or "P" position, the park/neutral position switch turned ON → sends a cancellation signal (ground voltage) to terminal 14 of the ECU.

#### (d) Clutch Switch (M/T)

When the clutch pedal is depressed, the clutch switch is turned ON → sends a cancellation signal (ground voltage) to terminal 13 of the ECU.

#### (e) Stop Light Switch

When the brake pedal is depressed, the SW B of stop light switch is turned OFF → the release valve (in actuator) is opened, and the SW A of stop light switch is turned ON → sends a cancellation signal to terminal 17 of the ECU.

Therefore, the operation of the cruise control system is canceled and the actuator is shut off due to the operation of these switches.

# Diagnosis System

## Output of Diagnostic Trouble Code

### READ DIAGNOSTIC TROUBLE CODE

#### (Type A)


- (a) Turn the ignition switch on.
- (b) Push the SET/COAST switch on, and keep it on.
- (c) Push the main switch on.
- (d) Check that the indicator light "CRUISE" light-on in the combination meter and after 3 seconds check that the indicator light "CRUISE" blinks.
- (e) Turn the SET/COAST switch off.
- (f) Meet the conditions listed below.
- (g) Read the diagnostic trouble code on the indicator light "CRUISE".

No.	Conditions	Indication code	Diagnosis
1	Push the cruise control switch SET/COAST on.	<p style="text-align: right;">BE1931</p>	SET/COAST circuit is normal.
2	Push the cruise control switch RESUME/ACCEL on.	<p style="text-align: right;">BE1932</p>	RESUME/ACCEL circuit is normal.
3	Vacuum switch is turned ON.	<p style="text-align: right;">BE1934</p>	Vacuum switch circuit is normal.
4	Each cancel switch turned ON. <ul style="list-style-type: none"> <li>• Cruise control switch (to CANCEL)</li> <li>• Stop light switch</li> <li>• Park/Neutral Position switch (to N or P Position)</li> <li>• Clutch switch</li> <li>• Parking brake switch</li> </ul>	<p style="text-align: right;">BE1935</p>	Each cancel switch is normal.
5	Drive approx. 40 km/h (25 mph) or over.	<p style="text-align: right;">BE1937</p>	Speed sensor circuit is normal.
6	Drive approx. 40 km/h (25 mph) or below.	<p style="text-align: right;">BE1938</p>	Speed sensor circuit is normal.

**HINT:**

- Indication codes appear in order from No. 1.
- If there is no indication code, perform diagnosis and inspection. (See page BE-64)
- Indication is stopped, when the MAIN switch is re-pushed.


(Type6)



- (a) If while driving with the cruise control on, the system is canceled by a malfunction in either the actuator, speed sensor or cruise control switch circuit, the cruise control indicator light "CRUISE" will blink 5 times.
- (b) While stopping, connect terminals 3 and 11 of the data link connector 1.  
HINT: Should the ignition switch turned off, the diagnostic trouble code will be erased from the computer memory.
- (c) Read the diagnostic trouble code on the indicator light "CRUISE".

	Indication code	Diagnosis
	<p>BE1939</p>	Normal.
11	<p>BE1940</p>	Control valve circuit of actuator is abnormal.
12	<p>BE2711</p>	Release valve circuit of actuator is abnormal.
21	<p>BE1941</p>	Speed sensor circuit is abnormal.
23	<p>BE1943</p>	*Vehicle speed has decreased by 16 km/h (10 mph) or more from the set speed.
32	<p>BE1945</p>	SET/COAST switch signal and RESUME/ACCEL switch signal stay on simultaneously.
34	<p>BE4342</p>	Control switch does not turn off before switching.
<p>* If the set speed can be maintained when the speed control switch is again set at SET/COAST, there is no malfunction .</p>		

When 41 code is indicated, replace the cruise control ECU.



HINT:



- Indication codes appear in order from No. 11
- If there is no indication code, perform diagnosis and inspection. (See page BE-84)

# Troubleshooting

You will find the troubles easier using the table well shown below. In this table, each number shows the priority of causes in troubles. Check each part in order.

Chart No.				C	A	B	E	G, H	F	I	I	D		
Inspection Item				Actuator	Main Switch	Control Switch	Stop Light Switch	Clutch Switch or Park/ Neutral Position Switch	Parking Brake Switch	Vacuum Switch	Vacuum Pump	Speed Sensor or Speedometer Cable	Speedometer Cable Function	Others
Diagnosis Code	Type B	Type A	ECU											
Problem														
<ul style="list-style-type: none"> <li>"CRUISE" indicator light blinks 5 time.</li> <li>Cruise control system does not set.</li> <li>Cruise control system does not operate.</li> </ul>	11		2	1										
	12		3	1			2							
	21		2									1		
	23		6	2						5	4	3	1	*2
	32		2			1								
	Normal	5	OK	8	7	1	2	3	4	5			6	*3
			NG	2								1		
Setting speed deviated on high or low side.	3	OK	6	5						4	3	2	1	
		NG								1				
Vehicle speed fluctuates when speed control switch turned to SET.			4	3								1	2	
Setting speed does not cancel when brake pedal depressed.	4	OK	3	1			2							
		NG	2				1							
Setting speed does not cancel when parking brake lever pulled.	4	OK	2	1					1					
		NG	2											
Setting speed does not cancel when shifted to "N" position. (A/T)	4	OK	2	1				1						
		NG	2											
Setting speed does not cancel when clutch pedal depressed. (M/T)	4	OK	2	1				1						
		NG	2											
Vehicle speed does not decrease when cruise control switch turned to COAST.	1	OK	3	1									2	
		NG	2			1								
Vehicle speed does not accelerate when cruise control switch turned to ACCEL.	2	OK	3	1									2	
		NG	2			1								
Vehicle speed does not return to memorized speed when control switch turned on RESUME.	2	OK	3	1									2	
		NG	2			1								
Setting speed does not cancel when cruise control switch turned to CANCEL.	4	OK	2	1										
		NG	2			1								
Speed can be set below about 40 km/h (25 mph).	5	OK	2	1								1		
		NG	2											
Cruise control will not disengage even at about 40 km/h (25 mph).	5	OK	2	1									1	2
		NG	3											
Acceleration response is sluggish when cruise control switch turned to "ACCEL" or "RESUME".	3	OK	4	3							2		1	*2
		NG								1	2			
": in the Speedometer			Vacuum Hose		*3: Vacuum Hose & Brake Fluid									



# Inspection Chart

## A INSPECTION OF POWER SOURCE CIRCUIT

Turn ignition switch on

Is ENGINE fuse normal?

No

Replace fuse.  
Is operation normal?

No

- Short circuit in wire harness between ENGINE fuse and terminal 2 of main relay.
- Inspect main relay. (See page [BE-82](#))

Yes

Yes

Fuse faulty.

### MAIN RELAY

#### INSPECT GROUND CONNECTION

Disconnect connector from main relay.  
Is there continuity between terminal 3 of main relay and ground?

No

- Open circuit in wire harness between terminal 3 of main relay and ground.
- Ground faulty.

Yes

#### INSPECT POWER SOURCE

Is there battery positive voltage between terminal 2 of main relay and ground with ignition switch turned on?

No

Open circuit in wire harness between ENGINE fuse and terminal 2 of main relay.

Yes

#### INSPECT MAIN RELAY OPERATION

Is main relay operation normal?  
(See page [BE-81](#))

No

Main relay faulty.  
Replace main relay. Then recheck system.

Yes

Is there continuity between terminal 6 on wire harness side connector and ground?

Yes

Short circuit in wire harness between terminals 6 of main relay and 12 of CC ECU.

No

Is there continuity between terminal 1 on wire harness side connector and ground?


Yes

Short circuit in wire harness between terminals 1 of main relay and 10 of CC ECU.


No

CONTINUED ON NEXT PAGE


CONTINUED FROM PREVIOUS PAGE




CONTINUED FROM PREVIOUS PAGE





CONTINUED ON PREVIOUS PAGE





# C INSPECTION OF ACTUATOR CIRCUIT





**D INSPECTION OF SPEED SENSOR CIRCUIT**

SPEED METER CABLE

**INSPECT SPEED METER CABLE**  
Does not meter fluctuate when driving at a steady speed?

Yes → Meter cable faulty.  
Replace meter cable. Then recheck system.

No  
Turn ignition switch off.

SPEED SENSOR

Disconnect connector from combination meter.

**INSPECT GROUND CONNECTION**  
Is there continuity between terminal 6 of wire harness side connector and ground?

No →

- Open circuit in wire harness between terminal B of combination meter and ground.
- Ground faulty.

Yes  
**INSPECT SPEED SENSOR OPERATION**  
Is there sensor operation normal?  
(See page BE-33).

No → Speed sensor faulty.  
Replace speed sensor. Then recheck system.

Yes  
Connect connectors to combination meter.

ECU

Disconnect connector from CC ECU and inspect connector on wire harness side as follows.  
Turn ignition switch on.


**INSPECT SPEED SENSOR CIRCUIT**  
Does the voltage between terminal 8 and ground change repeatedly from 0V to approx. 5V or more when speedometer shaft is turned?

No → Open or short circuit in wire harness between terminal 8 of CC ECU and terminal A of combination meter.


Yes  
CC ECU faulty.  
Replace CC ECU. Then recheck system.



## E INSPECTION OF STOP LIGHT SWITCH CIRCUIT



## F INSPECTION OF PARKING BRAKE SWITCH CIRCUIT



**G INSPECTION OF CLUTCH SWITCH CIRCUIT**

Turn ignition switch off.

**CLUTCH SWITCH****INSPECT GROUND CONNECTION**Disconnect connector from clutch switch.  
Is there continuity between terminal 2 of wire harness side connector and ground?

No

Open circuit in wire harness between terminal 2 of the clutch switch and ground.

Yes

**INSPECT CLUTCH SWITCH CONTINUITY**Is clutch switch continuity normal?  
(See page [BE-81](#))

No

Replace clutch switch.

Yes

Connect connector to clutch switch.

**ECU**

Disconnect connector from CC ECU and inspect connector on wire harness side as follows.

**INSPECT CLUTCH SWITCH CIRCUIT**

Is there continuity between terminal 13 and ground when clutch pedal is depressed?


No

Open circuit in wire harness between terminal 13 of ECU and terminal 1 of clutch switch.

Yes

CC ECU faulty.  
Replace CC ECU. Then recheck system.

# H INSPECTION OF PARK/NEUTRAL POSITION SWITCH CIRCUIT



## INSPECTION OF VACUUM CIRCUIT

Turn ignition switch off.

### VACUUM HOSE

Are there cracks or other damage on the vacuum hose?

Yes

Replace vacuum hose.

No

### VACUUM SWITCH

**INSPECT VACUUM SWITCH CIRCUIT**  
Disconnect connector from vacuum switch.  
Is there continuity terminal 2 of vacuum switch and ground?

No

- Open circuit in wire harness between terminal 2 of vacuum switch and ground.
- Ground faulty.

Yes

**INSPECT VACUUM SWITCH OPERATION**  
Is vacuum switch normal?  
(See page [BE-82](#))

No

Replace vacuum switch.

Yes

### VACUUM PUMP

**INSPECT GROUND CONNECTION**  
Disconnect connector from vacuum pump.  
Is there continuity between terminal 2 of wire harness side connector and ground?

No

- Open circuit in wire harness between terminal 2 of vacuum pump and ground.
- Ground faulty.

Yes

**INSPECT VACUUM PUMP OPERATION**  
Is vacuum pump operation normal?  
(See page [BE-82](#))

No

Replace vacuum pump.

Yes

Connect connector to vacuum switch and pump.

CONTINUED ON NEXT PAGE

CONTINUED FROM PREVIOUS PAGE

ECU

Disconnect connector from CC ECU and inspect connector on wire harness side as follows.

**INSPECT VACUUM SWITCH CIRCUIT**  
Is there continuity between terminal 1 1 and ground?

No

Open circuit in wire harness between terminal 1 1 of CC ECU and terminal 1 of vacuum switch.

Yes

Start engine (idling).

Is there continuity between terminal 1 1 and ground?

Yes

Short circuit in wire harness between terminal 1 1 of CC ECU and terminal 1 of vacuum switch.

No

Stop the engine.

**INSPECT VACUUM PUMP CIRCUIT**  
Is there continuity between terminal 2 and ground?

No

Open circuit in wire harness between terminal 2 of CC ECU and terminal 1 of vacuum switch.

Yes


Is there continuity between terminal 2 and ground when disconnect connector from vacuum pump?

Yes


Short circuit in wire harness between terminal 2 of CC ECU and terminal 1 of vacuum pump.

No

CC ECU faulty.  
Replace CC ECU. Then recheck system.

**J INSPECTION OF ECM SOLENOID CIRCUIT**

Wire Harness Side



e-20-1

# Cruise Control ECU Circuit Inspection of ECU Circuit


Disconnect the connector from the ECU and inspect the connector on the wire harness side as shown below.

Connection or Measure item	Check for	Tester Connection	Condition	Specified valve	
Data Link Connector 2	Continuity	1 - Ground	Short terminals between "Te" and "E1"	Continuity	
			Released	No continuity	
Vacuum pump		2 - Ground	Constant	Continuity *1	
Speed sensor (in combination meter)		8 - Ground	Vehicle moving slowly	1 pulse each 40 cm approx. (15.75 in.)	
Vacuum switch		11 - Ground	Vacuum	No vacuum	Continuity
				More than 70 + 30 mmHg 6.69 f 1.18 in. Hg 22.66 + 4.0 kPa	No continuity
Park/Neutral Position switch (A/T)		13 - Ground	Shift position	"N" or "P" position D, ., 2D, Dp or "R" position	Continuity No continuity
Clutch switch (M/T)		13 - Ground	Clutch pedal position	Depressed	Continuity
				Released	No continuity
Parking brake switch		14 - Ground	Parking brake lever position	Pulled	Continuity
	Released			No continuity	
Body ground	15 - Ground	Constant		Continuity	
Stop light switch	17 - 18	Brake pedal position	Depressed	Continuity *1	
			Released	No continuity	
CANCEL switch	Resistance	19 - Ground	CANCEL switch is pushed	Approx. 4180	
			Released	No continuity	
RESUME/ACCEL switch		19 - Ground	Cruise control switch position	RESUME/ACCEL switch is pushed	Approx. 68Ω
				Released	No continuity
SET/COAST switch		19 - Ground		SET/COAST switch is pushed	Approx. 1980
				Released	No continuity
Stop light switch and actuator (release valve)		3 - 16	Brake pedal position	Depressed Released	No continuity Approx. 71Ω
Actuator (control valve)		5 - 16	Constant	Approx. 380	
No. 2 solenoid valve		9 - Ground	Constant	less than 1511	
GAUGE fuse and indicator light	Voltage	4 - Ground	Ignition switch position	ON LOCK, ACC	Battery positive voltage No voltage
ENGINE fuse		6 - Ground	Ignition switch position	ON LOCK, ACC	Battery positive voltage No voltage
O/D circuit		7 - Ground	Ignition SW position	ON LOCK or ACC	Approx. 5V or more No voltage
ENGINE fuse, main switch and main relay		10 - Ground	Ignition switch ON and MAIN switch position	ON OFF	less than 0.3 V No voltage
		12 - Ground	Ignition switch ON and MAIN switch position	ON OFF	Battery positive voltage No voltage

\* 1 There is resistance in the circuit.

If circuit is as specified, replace the ECU.






## Parts Inspection

### 1. INSPECT SWITCHES (Main Switch/Continuity)

Terminal Switch position	1	2
OFF		
ON	○	○

If continuity is not as specified, replace the switch.  
(Cruise Control Switch /Continuity)




Terminal Condition	1/2	2/2	3/5	4/5
Constant	○	○	○	○

If continuity is not as specified, replace the switch.  
(Cruise Control Switch/Resistance)

Measure the resistance value between terminals 2/5 and 4/5 or 2/12.

Switch position	RESISTANCE (Ω)
OFF	No continuity
RESUME/ACCEL	Approx. 68
SET/COAST	Approx. 198
CANCEL	Approx. 418


If resistance value is not as specified, replace the switch.



### (Vacuum Switch /Operation)

- (a) Check that there is continuity between terminals with no vacuum.
- (b) Check that there is no continuity between terminals with a vacuum of  $170 \pm 30\text{mmHg}$  ( $6.69 \pm 1.18$  in. Hg,  $22.66 \pm 4.00$  kPa ) or above.

If operation is not as specified, replace the switch.



### (Stop Light Switch /Continuity)



Inspect the switch continuity between terminals.

Terminals Switch position	1	2	3	4
Switch pin free (Brake pedal depressed)	○	○	○	
Switch pin pushed in (Brake pedal released)		○	○	○

If continuity is not as specified, replace the switch.

(Clutch Switch /Continuity)

Inspect the switch continuity between terminals.

 <p>BE2737 G-2-2</p>	Terminal	1	2
	Condition		
	Switch pin free (Clutch pedal depressed)		
Switch pin pushed in (Clutch pedal released)			

If continuity is not as specified, replace the switch.

**(Brake Fluid Level Warning Switch/Operation)**

See step 2 on page BE-39.

**(Parking Brake Switch/Operation)**

See step 2 on page BE-40.

**(Park/Neutral Position Switch /Operation)**

See pages AT-26, 79, 137 or 196.


**2. INSPECT SPEED SENSOR**


See step 2 on page BE-34.

**3. INSPECT SLIP RING**

(Continuity)

Inspect the continuity between terminals.



Terminal	A-2	A-3	A-4	B-4	B-5	B-6
Condition						
Constant						


If continuity is not as specified, replace the slip ring.


**4. INSPECT MAIN RELAY**

(Operation)

- (a) Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminals 3 and 4.
- (b) Connect the positive (+) lead from the voltmeter to terminal 6 and the negative (-) lead to terminal 3, check that there is battery positive voltage.
- (c) Change the positive (+) lead to terminal 1, check that there is voltage less than 0.3V.

If operation is not as specified, replace the relay.






## 5. INSPECT VACUUM PUMP

(3VZ-E Engine)

- Connect a vacuum gauge to the ACT side of the pump.
- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2.
- Check that there is a vacuum of 200 mmHg (7.87 in. Hg, 26.7 kPa) or above.


If operation is not as specified, replace the pump.



(22R-E Engine)

- Connect a vacuum gauge to the ACT side of the pump.
- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2.
- Check that there is a vacuum of 200 mm Hg (7.87 in.Hg, 26.7 kPa) or above.

If operation is not as specified, replace the pump.



## 6. INSPECT ACTUATOR


(Resistance)

Measure the resistance value between terminals as follows.

**Resistance: 1-3 Approx. 71Ω**

**2-3 Approx. 38Ω**

If the resistance value is not as specified, replace the actuator.



(Operation)

- Connect the positive (+) lead from the battery to terminals 1 and 2, and the negative (-) lead to terminal 3.
- Slowly apply vacuum from 0 to 300 mmHg (0 to 11.81 in.Hg, 0 to 40.0 kPa), check that the control cable can be pulled smoothly.

**Cable stroke: Approx. 36 mm (1.42 in.)**

- With the vacuum stabilized, check that the control cable does not return.

HINT: As you apply and hold the vacuum with the vacuum pump, the drawn in diaphragm will in some cases return. This does not indicate a malfunction. Actuator leakage is allowable.

- Disconnect terminal 1 or 2 and check that the control cable returns to its original position and the vacuum returns to 0 mmHg (0 in. Hg, 0 kPa).

If operation is not as specified, replace the actuator.

